


Smart Tech



Display

1. Fan Speed: Manual Low, Med, High, and Auto
2. Room Temperature Display
3. Set Temperature
4. Auxiliary Heater is On (if one is installed)
5. Cooling Mode
6. Heating Mode
7. Button Lock



Buttons

8. Mode: Push to select Cooling or Heating Mode
9. Fan: Push briefly to select fan speed from Low, Med, High to Auto
10. Thermostat ON/OFF
11. Temp Up.
12. Temp Down

Error

Alarm will appear if there is an error for the on board or remote sensor

E0 Onboard Sensor

E1 Remote Sensor

Button Lock/Unlock

Push and hold + and - buttons simultaneously for 5 sec to LOCK all buttons

Push and hold + and - buttons simultaneously for 5 sec to UNLOCK all buttons