

How to use your ecobee Thermostat.

Get to know your display screen.

Weather

This week's local weather forecast.
(if connected to your wifi)

System mode

System set to automatic
changeover for heat and cool.

Main menu with options

Adjust your schedule and
more.

Indoor humidity

Indoor temperature

Change temperature

Air quality

Remote temperature sensor

Place on opposite side of
the room, out of the sun.



ecobee


UNILUX
CRFC · CORP

For more information please scan:

